



Model: PST-1800MF

Worldwide Input
Multi Output

Operation Manual

XG Brand PST-1800MF is a high quality switching type AC/DC adaptor, with many great and useful features: For most small home electronic appliances and devices such as 5" TVs, Walkmans, Discmans, MP3 Players, Game Boys, Toys, Calculators, Answering Machines, Cellular, Cordless and Video Phones and so on.




Features

- Worldwide Input: AC 100-240v, 50/60Hz, adjusting automatically
- Regulated Output: DC 3 - 4.5 - 6 - 7.5 - 9 - 12V, 1800mA max
- High Efficiency: More than 80%
- Six Adaptor Plugs: For use with most small home electronic devices
- Short Circuit and Overload Protection (SCOP): Self-protection against short circuit and overload
- Innovative Design on Voltage Button Selector
- LED Power Indicator
- Compact in size, Light in weight, Convenient to use, Easy to Carry

INSTRUCTIONS

- Check the needed voltage on your electronic device. Determine the proper output voltage and turn the button to set the selector switch to the proper voltage.
- Six Adaptor Plugs are supplied with this adaptor. Select the plug that best fits the external power jack (sometimes labeled as **DC In**) on the device. (See Fig. 1)
- Check instructions and rating of the device and determine the polarity before inserting the chosen Adaptor Plug into the external power jack. Common symbols for tip polarity are shown in Fig. 2.
- Plug the adaptor into a standard electric wall outlet and operate your device as usual.



(Fig 1)

CONNECTOR	PLUG	TIP POLARITY
	+	
	-	

(Fig 2)

CAUTION

- It is normal for this unit to generate some heat when working at its maximum capacity for an extended period of time.
- Carefully check and set the DC voltage on the unit. Your device may not work properly if improper voltage is chosen.
- Do Not set the polarity in reverse. Reversed polarity may cause permanent damage to the device.
- Do Not change output voltage when the unit is working to prevent possible damage to the device.
- Disconnect IMMEDIATELY this unit from power source to prevent any possible damage when the device does not operate or when the LED is turned out by its SCOP. Check instructions above and retry to continue operation. Do not open, alter and modify this unit.
- It is a commonly known international practice that due to the properties of switching type circuit, use of this item with radios, specially for reception of AM band programs, is not recommended as it may cause unwanted noise during operation.

www.spiketronix.com

Distributed by: e-dustry, inc.

California, U.S.A.

edustry@hotmail.com

4BT15-3124-041